

MS-MBA-4-H2		Instruction Manual			
Date	Prepared by	Approved by	Document nos	Revision	
27 Jul 2023	Ray Ling	Pavel	MS-MBA-4-H2-IM-001	0	

INSTRUCTION MANUAL MS-MBA-4-H2

TABLE OF CONTENTS:

1.00 BEAMS & CONNECTORS:

- 1.10 Plan View Resultant Beam Layout
- 1.20 Connector Ports Table
- 1.30 Connector Detail
- 1.40 Connector Layout

2.00 PATTERN DIAGRAM

- 2.10 Horizontal Pattern
- 2.20 Vertical Pattern

3.00 MANUAL TILT ADJUSTMENT

4.00 BRACKET INSTALLATION

- 4.10 Bolts & Nuts Requirements
 - 4.11 Bolts & Nuts
 - 4.12 Bracket
- 4.20 Tools Requirement
 - 4.21 Adjustable Spanner
 - 4.22 M12 Spanner
- 4.30 Bracket Spacing & Installation Sample

Revision History:


Date	Description	Revised by	Revision nos.

email: info@matsing.com website: www.matsing.com Page 1 / 5

1.00 BEAMS & CONNECTORS:


1.10 Plan View Resultant Beam Layout

1.20 Connector Ports Table



BEAM	BEAM	BEAM	BEAM
4	3	2	1
Port 7	Port 5	Port 3	Port 1
(+45°)	(+45°)	(+45°)	(+45°)
Port 8	Port 6	Port 4	Port 2
(-45°)	(-45°)	(-45°)	(-45°)

1.30 Connector Detail




5

2


1.40 Connector Layout

MS-MBA-4-H2


REAR VIEW CONNECTOR LAYOUT



2.00 PATTERN DIAGRAM 2.10 Horizontal Pattern




2.20 Vertical Pattern



3.00 MANUAL TILT ADJUSTMENT

	The MBA antenna come in RET mode as default, but if needed can also be manually
1	adjusted. To do so, please unscrew the waterproof cap behind the element whose tilt is
	to be adjusted.
2	By Default the knob is on engaged mode, pull out the handle for manual tilt adjustment, turn the handle to change the tilt.
	adjustment, turn the handle to change the tilt.
3	When done, push the handle back in, screw the waterproof cap back to the position.



Unscrew/Screw the cap for tilt adjustment process



Engaged with internal RET motor position



Pull handle out to disengaged RET for tilt adjustment



4.00 BRACKET INSTALLATION

4.10 Bolts & Nuts Requirements

Bracket	Bolts		Nuts	
Qty	Size	Qty	Size	Qty
2	M12 x 200mm	4	M12	10

4.11 Bolts & Nuts



4.20 Tools Requirement
4.21 Adjustable Spanner



4.12 Bracket



4.22 M12 Spanner



4.30 Bracket Spacing & Installation Sample

