



MS-MBA-4.2-H2-L2

MS-MBA-4.2-H2-T2

REAR VIEW CONNECTOR LAYOUT





MS-MBA-4.2-H2-L2

MS-MBA-4.2-H2-T2

REAR VIEW CONNECTOR LAYOUT

