

Date	Prepared by	Approved by	Document nos	Revision
19 Sep 2023	Ray Ling	Pavel	MS-SB34-FH-IM-001	0

INSTRUCTION MANUAL MS-SB34-F-H

TABLE OF CONTENTS:

1.00 BEAM DIRECTION, CONNECTORS LAYOUT & DIMENSIONS:

- 1.10 Beam Direction
- 1.20 Connector Layout
- 1.30 Antenna Dimensions

2.00 PATTERN DIAGRAM


- 2.10 FB Horizontal Pattern
- 2.20 FB Vertical Pattern
- 2.30 HB Horizontal Pattern
- 2.40 HB Vertical Pattern

Revision History:


Date	Description	Revised by	Revision nos.

1.00 BEAM DIRECTION, CONNECTORS LAYOUT & DIMENSIONS:


1.10 Beam Direction



1.20 Connector Layout




1.30 Antenna Dimensions




2.00 PATTERN DIAGRAM


2.10 FB Horizontal Pattern



2.20 FB Vertical Pattern



2.30 HB Horizontal Pattern



2.40 HB Vertical Pattern

