

RRH Plumbing Diagrams

MS-MBC-4-H4-12

Table of contents

1. Table of contents
2. Revision History
3. Applicable RRH Models
4. Ericsson Diagram
5. Ericsson Port Mapping
6. Nokia Diagram
7. Nokia Port Mapping
8. Samsung Diagram
9. Samsung Port Mapping



MATSING[®]

LENS TECHNOLOGY ENABLED

Revision History


Revision	Date	Details
1	11/14/2024	Initial Release
2		
3		

Applicable RRH Models

Ericsson RRHs	Nokia RRHs	Samsung RRHs
PCS/AWS (Ericsson 8843)	PCS/AWS (Nokia AirScale AHFIB)	PCS/AWS (Samsung RFV01U-D1A)
WCS (Ericsson 4402)	BRS (Nokia AZHL)	
BRS (Ericsson 8863)		

MS-MBC-4-H4-12 with B2/B66, B30 and n41 RRH (Ericsson 8843-4402-8863)

REAR VIEW




Ericsson Port Mapping

MS-MBC-4-H4-12	Node 1: B2/B66 RRH (Ericsson 8843), B30 RRH (Ericsson 4402) and n41 RRH (Ericsson 8863)	Node 2: B2/B66 RRH (Ericsson 8843), B30 RRH (Ericsson 4402) and n41 RRH (Ericsson 8863)	Node 3: B2/B66 RRH (Ericsson 8843), B30 RRH (Ericsson 4402) and n41 RRH (Ericsson 8863)	Node 4: B2/B66 RRH (Ericsson 8843), B30 RRH (Ericsson 4402) and n41 RRH (Ericsson 8863)
Port 1	A/E – ANT 1 – A			
Port 2	B/F – ANT 2 – B			
Port 3	C/G – ANT 3 – C			
Port 4	D/H – ANT 4 – D			
Port 5		A/E – ANT 1 – A		
Port 6		B/F – ANT 2 – B		
Port 7		C/G – ANT 3 – C		
Port 8		D/H – ANT 4 – D		
Port 9			A/E – ANT 1 – A	
Port 10			B/F – ANT 2 – B	
Port 11			C/G – ANT 3 – C	
Port 12			D/H – ANT 4 – D	
Port 13				A/E – ANT 1 – A
Port 14				B/F – ANT 2 – B
Port 15				C/G – ANT 3 – C
Port 16				D/H – ANT 4 – D
AISG IN	RET			

MS-MBC-4-H4-12 with B25/B66 and n41 RRH (Nokia AHFIB-AZHL)

REAR VIEW




Nokia Port Mapping

MS-MBC-4-H4-12	Node 1: B25/B66 RRH (Nokia AirScale AHFIB) and n41 RRH (Nokia AZHL)	Node 2: B25/B66 RRH (Nokia AirScale AHFIB) and n41 RRH (Nokia AZHL)	Node 3: B25/B66 RRH (Nokia AirScale AHFIB) and n41 RRH (Nokia AZHL)	Node 4: B25/B66 RRH (Nokia AirScale AHFIB) and n41 RRH (Nokia AZHL)
Port 1	ANT 1 – ANT 1			
Port 2	ANT 2 – ANT 2			
Port 3	ANT 3 – ANT 3			
Port 4	ANT 4 – ANT 4			
Port 5		ANT 1 – ANT 1		
Port 6		ANT 2 – ANT 2		
Port 7		ANT 3 – ANT 3		
Port 8		ANT 4 – ANT 4		
Port 9			ANT 1 – ANT 1	
Port 10			ANT 2 – ANT 2	
Port 11			ANT 3 – ANT 3	
Port 12			ANT 4 – ANT 4	
Port 13				ANT 1 – ANT 1
Port 14				ANT 2 – ANT 2
Port 15				ANT 3 – ANT 3
Port 16				ANT 4 – ANT 4
AISG IN	RET			

MS-MBC-4-H4-12 with B2/B66 RRH (Samsung RFV01U-D1A)

REAR VIEW



Samsung Port Mapping

MS-MBC-4-H4-12	Node 1: B2/B66 RRH (Samsung RFV01U-D1A)	Node 2: B2/B66 RRH (Samsung RFV01U-D1A)	Node 3: B2/B66 RRH (Samsung RFV01U-D1A)	Node 4: B2/B66 RRH (Samsung RFV01U-D1A)
Port 1	ANT 1 – ANT 5			
Port 2	ANT 2 – ANT 6			
Port 3	ANT 3 – ANT 7			
Port 4	ANT 4 – ANT 8			
Port 5		ANT 1 – ANT 5		
Port 6		ANT 2 – ANT 6		
Port 7		ANT 3 – ANT 7		
Port 8		ANT 4 – ANT 8		
Port 9			ANT 1 – ANT 5	
Port 10			ANT 2 – ANT 6	
Port 11			ANT 3 – ANT 7	
Port 12			ANT 4 – ANT 8	
Port 13				ANT 1 – ANT 5
Port 14				ANT 2 – ANT 6
Port 15				ANT 3 – ANT 7
Port 16				ANT 4 – ANT 8
AISG IN	RET			